

一、Application

convenience stores, supermarkets, beauty stores and so on

二、Installation Instruction



1

2 Size

Power Track 30*60 mm Power Track 30*70 mm

Power Track 30*80 mm Connector

3 Turn off the power

4 Install power track

Put the track input wire from the stand column hole

5 Install backboard

6 Install connector

7 Install Bracket

8 Install Light

Pass the light wire connector through the slot


↑ Install light

9 Install Shelf layer board


Connect the corresponding light connector

Wireless Power Track

10 Fixed layer board




11 Connect the power with power track




Please read carefully before connection drive information, to ensure that the driver and the light and lanterns of the connected matches.

12 Turn on the power




Change layer board position

1 Turn off power



2 Remove the screws holding the layer board and remove the lower layer board




3 Disconnecting connector


Disconnecting light connector



4 Change bracket position




5 Install Shelf layer board



Connect the corresponding light connector

6 Turn on power



3、 Attention



1, lights and layer board should be installed by qualified electrician, wiring requirements meet national standards.

2. Do not change the lamps and lanterns at will or change the adjusting parts by yourself to avoid electric shock, fire and other accidents.

3. Before maintenance, installation, and replacement of power supply or electrical appliances, ensure that the power supply is cut off.

4. Do not install such lamps in damp and leaking places.

5. Under no circumstances shall lamps be covered with thermal insulation gaskets or similar materials.

6, when the lamp is found abnormal, please quickly cut off the power supply, and please professional inspection or contact with the local dealer.

4. Cleaning and maintenance

1. In order to use this product safely and efficiently, please clean and inspect it regularly (once every 6 months).

2, clean lamps and lanterns, please wipe with soft cloth dipped in detergent water, and then wipe with a dry cloth.

3, please do not use thinner, gasoline and other volatile to wipe test, so as not to light discoloration or damage.

